

# STELCO - HBS Series

## Optimal Sizing For Applications Guide

		Series	HBS 180 CS	HBS 280 CS	HBS 380 CS	HBS 580 CS	HBS 610 CS	HBS 680 CS	HBS 720 CS	HBS 765 CS	HBS 788 CS	HBS 795 CS	HBS 850 CS	HBS 980 CS
Road construction and landscaping	Tearing up concrete and asphalt road surfaces		■	■	■	■	■	■						
	Landscape gardening and landscaping		■	■	■	■	■	■						
	Trenchwork for utilities				■	■	■	■	■					
Demolition	Masonry		■	■	■	■	■	■						
	Non-reinforced concrete					■	■	■	■	■				
	Reinforced concrete					■	■	■	■	■				
	Heavily-reinforced concrete									■	■	■	■	■
Rock breaking	Reducing oversizes									■	■	■	■	■
	Trenchwork									■	■	■	■	■
	Bench levelling									■	■	■	■	■
	Quarrying									■	■	■	■	■
Mining	Clearing the roof					■	■	■	■	■	■	■	■	■
	Bench levelling									■	■	■	■	■
	Tunnelling									■	■	■	■	■
Underwater applications	Demolition							■	■	■	■	■	■	■
	Deepening shipping channels									■	■	■	■	■
High-temperature applications	Removing incrustations				■	■	■	■						
	Breaking out ladle linings			■	■	■	■	■	■					
	Breaking up slag								■	■	■	■	■	■